

Manual, Assembly instruction: Brodit 854699

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding air vent frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the upper part of the ProClip up into the seam/gap between the air vent and the surrounding panel frame.

3. Place your index fingers on top of the ProClip and your thumbs underneath the ProClip. Push up on the lower part of the ProClip so it flexes upward and hooks into the seam/gap next to the gap opener. Press firmly down on the lower inside of the ProClip to make sure the angled edge goes all the way into the seam/gap. Pull out the gap opener.

4. The ProClip is in place.