

Manual, Assembly instruction: Brodit 854705

Center mount ONLY for models with speaker cover on top of the dashboard.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the dashboard and the top cover, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Place the front hooked edge of the ProClip into the gap between the gap openers. Slide the ProClip forward until you hear or feel it click downward.
3. Place your fingers on top and front of the ProClip and press down and forward for best possible attachment of the adhesive tape. Pull out the gap openers.
4. The ProClip is in place.