

Manual, Assembly instruction: Brodit 854706

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the top part of the ProClip over the air vent dashboard edge.

2. Press down on top of the ProClip with your one hand and forward on the lower part of the ProClip with your other hand so the angled lower edge hooks around the air vent edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.