

## Manual, Assembly instruction: Brodit 854711

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook the angled edge on the lower part of the ProClip around the upper air vent edge.
3. Press forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.