

Manual, Assembly instruction: Brodit 854713

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the upper part of the ProClip onto the upper air vent edge.
2. Press forward on the lower part of the ProClip so the angled edge hooks into the gap/seam between the air vent and the surrounding panel frame.
3. This ProClip can also be attached over the center air vent.
4. The ProClip is in place.