

Manual, Assembly instruction: Brodit 854718

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the dashboard and center console panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.
2. Place the front part of the ProClip around the dashboard edge.
3. Press firmly forward on the upper part of the ProClip so it flexes forward and the angled edge hooks around the panel edge between the the gap openers. Press until you see or hear/feel it click into place. Pull out the gap openers.
4. The ProClip is in place.