

## Manual, Assembly instruction: Brodit 854723

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the ProClip upward into the gap between the air vent and the surrounding frame overhang.
2. Press the lower part of the ProClip upward and forward. Hook the angled edge into the gap between the air vent and the dashboard.
3. Press downward on the lower part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.