

## Manual, Assembly instruction: Brodit 854733

Center mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the left edge on the ProClip into the gap between the frame surrounding the instrument panel and the dashboard.

**2.** Flip the ProClip forward so the curved left edge hooks behind the frame surrounding the instrument panel.

**3.** Hook the angled edge on the right part of the ProClip into the gap between the control panel and the dashboard. Press the right part of the ProClip toward the dashboard so the angled edge goes all the way into the gap.

**4.** The ProClip is in place.