

Manual, Assembly instruction: Brodit 854734

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the ProClip into the gap in the center console sidewall to widen the gap.

2. Place the curved edge on the right aprt of the ProClip by the gap next to the gap opener. Press forward on the gap opener to widen the gap even more. In the same time: Press the curved edge on the right part of the ProClip into the gap next to the gap opener. Press on the right side of the ProClip so the curved edge hooks properly around the sidewall panel. Pull out the gap opener.

3. Hook the left part of the ProClip over the center console edge.

4. The ProClip is in place.