

Manual, Assembly instruction: Brodit 854737

Angled mount NOT for Seat Mii Entry. NOT for Skoda Citigo Active and Arctic. NOT for Volkswagen UP Take Up.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap.
2. Hook the angled edge on the upper part of the ProClip into the gap between the upper and the lower section of the dashboard.
3. Press the ProClip forward and hook the angled edge into the gap next to the gap opener. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.