

Manual, Assembly instruction: Brodit 854740

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed both on the left and the right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.

2. Press forward on the ProClip so the angled upper edge hooks into the gap between the frame surrounding the air vent and the dashboard.

3. Press until you hear/feel that the angled edge snaps into place in the gap. Press downward on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.