

Manual, Assembly instruction: Brodit 854747

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: It is very important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding frame.

2. Press downward on the lower part of the ProClip so the angled edge goes all the way into the gap.

3. Press the upper part of the ProClip downward and the forward. Hook the thin upper edge of the ProClip into the gap between the air vent and the surrounding frame.

4. The ProClip is in place.