

Manual, Assembly instruction: Brodit 854755

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the center console and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the right part of the ProClip into the gap above the gap opener. Flip the ProClip toward the center console so the curved right edge hooks behind the dashboard. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the center console and the control panel. Pull the left part of the ProClip toward you and hook it over the frame surrounding the center console. Press the lower corner of the angled left edge into the gap above the gap opener.

3. Move the gap opener so it is placed above the ProClip. Press forward on the upper corner of the left part so all of the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.