

Manual, Assembly instruction: Brodit 854756

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the stereo and the surrounding frame, to widen the gap (place one to the right of the stereo and the other over the stereo) Press the lower corner of the grooved vertical part of the ProClip into the gap above the right gap opener.
2. Press forward on the ProClip so all of the vertical grooved edge goes into the gap.
3. Press forward on the upper part of the ProClip so the grooved horizontal part goes into the gap next to the gap opener. Pull out the gap openers.
4. The ProClip is in place.