

Manual, Assembly instruction: Brodit 854766

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the panel surrounding the air vent and the dashboard overhang to widen the gap. Peel off the adhesive tape covers on the ProClip
2. Place the lower edge of the ProClip onto the lower edge of the air vent.
3. Press the upper part of the ProClip downward and forward and press the upper edge into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.