

Manual, Assembly instruction: Brodit 854767

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console frame and the center console sidewall to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap in the center console sidewall and press it forward so the sidewall pops out and the edge of the short side becomes visible. Press the right side of the ProClip forward so the angled edge hooks around the edge of the sidewall above the gap opener. Pull out the gap opener. Pull out the gap opener.

3. Press leftward on the right side of the ProClip so the sidewall is pressed back into place.

4. The ProClip is in place.