

Manual, Assembly instruction: Brodit 854774

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the padded part of the dashboard, to widen the gap. Start with the left corner and press the grooved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press forward on the right lower part of the ProClip to press the remaining part of the grooved edge into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the air vent frame and the padded part of the dashboard. Press forward on the upper part of the ProClip with your right hand. Press until you see or hear/feel the angled edge click into the gap next to the gap opener. Press down on top of the ProClip with you left hand so to make sure the angled edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.