

Manual, Assembly instruction: Brodit 854775

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip around the edge of the trim. Slide the ProClip to the left.

2. Place your index finger underneath the top of the ProClip and push upward and hook the angled edge over the air vent edge.

3. Press down on top of the ProClip so the angled edge goes into the seem/gap between the air vent and the surrounding panel frame. Close the glove compartment door.

4. The ProClip is in place.