

Manual, Assembly instruction: Brodit 854776

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the air vent panel frame and the padded part for the dashboard. Press firmly forward until you see or hear/feel it click into place.

2. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the padded part of the dashboard, to widen the gap. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press forward until you see or hear/feel it click into place. Pull out the gap opener.

3. This ProClip can be attached over either air vent.

4. The ProClip is in place.