

Manual, Assembly instruction: Brodit 854784

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of one of the enclosed gap openers into the gap between the air vent panel frame and the console ledge, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Flip the ProClip upwards and forward towards the center area of the dashboard so the angled edge on the lower part of the ProClip hooks behind the edge of the trim. Pull out the gap opener.

2. On each side of the ProClip, press the gap openers into the gap between the air vent panel frame and the dashboard. Start with the gap opener to the left of the ProClip. Push on the upper part of the ProClip so it flexes forward and hooks around the panel edge between the gap openers. Pull out the gap openers.

3. Attach the face plate to the ProClip with the enclosed screws.

4. The ProClip is in place. This ProClip can be attached also over the right air vent.