

Manual, Assembly instruction: Brodit 854785

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: The attaching part (the smallest part). Part 2: The ProClip faceplate. Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: The attaching part (the smallest part). Part 2: The ProClip faceplate.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console panel and the console edge, to widen the gap. Peel off the cover of adhesive tape on the Part 1. Place the thin edge of Part 1 against the gap below the gap opener in the exact same position and height as in the picture.

2. Press the thin edge into the gap and at the same time: press Part 1 to the right until you see or hear/feel it click into place. Pull out the gap opener.

3. Press a screwdriver (Philips) through the predrilled holes in Part 2 to open the holes. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip to the right and press the adhesive tape on Part 2 to the center panel. Hold the ProClip in that position and tighten the screws.

4. The ProClip is in place.