

Manual, Assembly instruction: Brodit 854786

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. 1 Hold the ProClip in a horizontal position and press the angled edge into the gap between the wood grain trim and the dashboard.

2. Flip the ProClip down, towards the floor console, so the angled edge on the upper part of the ProClip hooks behind the trim. Position the vertical grooved piece on the back of the lower part of the ProClip against the gap between the climate control panel and the padded console edge.

3. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap. Press until you see or hear/feel it click into place.

4. The ProClip is in place.