

Manual, Assembly instruction: Brodit 854789

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the two dashboard sections, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press firmly on the lower part of the ProClip so it flexes downward and hooks around the edge of the panel section.
4. The ProClip is in place.