

Manual, Assembly instruction: Brodit 854791

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the angled edge of the ProClip into the gap between the the two padded parts of the dashboard.

2. Press firmly forward so the angled lower edge goes all the way into the gap.

3. Press down on top of the ProClip with your fingers and forward on the upper part off the ProClip with your thumb so the grooved edge goes into the gap between the padded dashboard ledge and the panel frame. Press until you see or hear/feel it click into place.

4. The ProClip is in place.