

Manual, Assembly instruction: Brodit 854795

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded part of the dashboard, to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener. **2** press the gap opener into the gap between the air vent panel frame and the center console panel frame. Place your fingers onto the lower part of the ProClip as shown in the picture.

3. With your index fingers press down and with your thumbs press forward so the angled edge on the ProClip goes into the seam/gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.