

Manual, Assembly instruction: Brodit 854799

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard surrounding the glove compartment. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the control panel and the center console edge. Flip the ProClip leftward so the angled right edge hooks behind the dashboard surrounding the glove compartment.

3. Hook the angled edge on the left part of the ProClip into the gap above the gap opener. Press forward on the left side of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.