

Manual, Assembly instruction: Brodit 854802

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the two panels shown in the photo, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip mount into the gap between the gap openers. It will help to insert the left side first and then press the right side in. Pull out the gap openers.

2. Press a gap opener into the seam between the air vent frame and padded dashboard. Rotate/Flip the ProClip upward and forward. Press forward on the upper part of the ProClip until the angled edge snaps into the gap next to the gap opener.

3. Press down on the top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.