

Manual, Assembly instruction: Brodit 854805

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the trim and the dashboard.

2. Flip the ProClip downward/forward so the curved upper edge hooks behind the trim. Adjust the ProClip position sideways so the grooved left edge is placed in front of the gap between the climate control panel and the surrounding frame.

3. Press the grooved edge on the left part of the ProClip into the gap between the climate control panel and the surrounding frame. Press until you hear/feel it snaps into place.

4. The ProClip is in place.