

Manual, Assembly instruction: Brodit 854808

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the right part of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the center console and the surrounding frame. Hook the angled edge on the left part of the ProClip into the gap below the gap opener. Press downward on the left side of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.