

Manual, Assembly instruction: Brodit 854809

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the right part of the ProClip into the gap between the air vent and the surrounding frame. Press the right edge into the gap. Pull the ProClip toward you so the gap is widened, in the same time press the angled edge all the way into the gap.
2. Press the grooved edge on the left part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
3. Press forward on the left part of the ProClip so you hear/feel it snaps into place.
4. The ProClip is in place.