

Manual, Assembly instruction: Brodit 854815

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap obliquely above the air vent. Peel off the adhesive tape covers on the ProClip. Press/Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downward on top of the ProClip so all of the the curved angled edge goes all the way into the gap. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard to widen the gap obliquely below the air vent. Pull the lower part of the ProClip downward and hook the angled edge into the gap next to the gap opener. Press upward on the lower part of the ProClip so all of the curved angled edge goes all the way into the gap. Pull out the gap opener.

3. This ProClip can be placed onto any of the air vents (also onto the one placed on the left side of the steering wheel).

4. The ProClip is in place.