

Manual, Assembly instruction: Brodit 854817

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the thin frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the left part of the ProClip into the gap below the gap opener.

2. Press/Flip the right side of the ProClip forward so the curved left edge hooks behind the frame surrounding the control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the dashboard sections. Press the right side of the ProClip forward so the grooved edge goes into the gap below the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.