

Manual, Assembly instruction: Brodit 854820

Center mount MAY partially block information display.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the lower part of the ProClip around the upper air vent edge.

2. Press firmly forward on the upper part of the ProClip so the angled edge on the long end of the ProClip flexes forward and hooks into the gap in the dashboard by the information/navigation screen. Press firmly down on top of the ProClip with your fingers to make sure the angled edge is all the way into the gap

3. The ProClip mount is in place.

4. The ProClip mount is in place.