

Manual, Assembly instruction: Brodit 854822

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the seam/gap between the air vent and the frame surrounding the display, to widen the gap. At the same time press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press down on top of the ProClip with your fingers so it flexes down. Hook the angled edge under the air vent panel edge, and release the pressure. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.