

Manual, Assembly instruction: Brodit 854823

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the console edge and the console edge panel, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press/hook the angled edge on the right side of the ProClip into the gap next to the gap opener.
3. Press firmly forward on the left side of the ProClip so the angled edge flexes forward and hooks around the side panel edge. Pull out the gap opener.
4. The ProClip is in place.