

Manual, Assembly instruction: Brodit 854827

Angled mount ONLY for models with factory navigation. Maximum width of installed holder: 70 mm.



Please read all of the instructions and look at the pictures before attaching the ProClip. Device holder must not be wider than 7cm, or it will block the navigation screen when opening

1. Press the thin end of the enclosed gap opener into the gap between the padded part of the dashboard and the frame surrounding the stereo, to widen the gap. Open the glove compartment door. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Hook the angled edge on the right side of the ProClip around the sidewall edge.

3. Place your fingers on the right side of the ProClip and push firmly to the left, towards the stereo, so the angled edge on the left side goes into the gap above the gap opener. Press firmly forward with your thumb to make sure the angled edge goes all the way into the gap. Pull out the gap opener. Close the glove compartment door.

4. The ProClip is in place.