

Manual, Assembly instruction: Brodit 854828

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the padded part of the dashboard and the center console panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Hook the angled edge on the right side of the ProClip around the left side of panel frame edge surrounding the air vent.
3. Press slightly forward/leftward on the gap opener to widen the gap further. In the same time press firmly forward on the left side of the ProClip so the angled edge hooks into the gap above the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.
4. The ProClip is in place.