

Manual, Assembly instruction: Brodit 854833

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap on the upper part of the front side of the center console pillar, to widen the gap. Slide the gap opener downward. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Place the angled edge on the right side of the ProClip around the console pillar back edge.

3. Press firmly forward on the left front side of the ProClip so the angled edge on the left/front side flexes forward and hooks into the seam/gap above the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.