

Manual, Assembly instruction: Brodit 854843

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the stereo and the center console frame around the radio, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the left side of the ProClip all the way into the gap below the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the console sidewall and the padded part of the dashboard. Push firmly forward on the right side of the ProClip face plate with your thumb so the angled edge flexes forward and hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.