

Manual, Assembly instruction: Brodit 854844

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the U-shaped edge on the upper part of the ProClip around the lower air vent edge. Pull the ProClip downward so it attaches properly.

2. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the seam/gap in the panel below the air vent. Press until you see or hear/feel it click into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.