

Manual, Assembly instruction: Brodit 854845

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the U-shaped edge on the upper part of the ProClip around the lower air vent edge. Pull the ProClip downward so it attaches properly.
2. Position the the grooved edge on the lower part of the ProClip against the seam/gap below the air vent.
3. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the seam/gap. Press until you see or hear/feel it click into place.
4. The ProClip is in place.