

Manual, Assembly instruction: Brodit 854846

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Flip the ProClip so the inside is facing you and press the angled/curved right edge into the gap in the console sidewall.

2. Flip the ProClip towards you so the angled/curved right edge goes all the way into the gap and hooks behind the sidewall edge.

3. Place your fingers behind the ProClip and pull towards you, and hook the angled edge on the left side of the ProClip over the console edge.

4. The ProClip is in place.