

Manual, Assembly instruction: Brodit 854847

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the air vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press/hook the angled edge on the upper part of the ProClip into the gap next to the gap opener.

2. Place you index finger behind the ProClip and pull it towards you and press down at the same time so the angled edge on the lower part of the ProClip hooks around the front edge of the dashboard ledge. Pull out the gap opener.

3. This ProClip also fits in front of the right air vent.

4. The ProClip is in place.