

Manual, Assembly instruction: Brodit 854850

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. 1 Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward/forward so the curved upper edge hooks behind the frame surrounding the control panel. Pull the lower part of the ProClip downward and press the angled edge into the gap between the dashboard and the center console.

3. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.