

Manual, Assembly instruction: Brodit 854853

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip exactly as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the panel surrounding the display, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press forward on the lower part of the ProClip, in the same time press downward on top of the ProClip so the ProClip flexes slightly.

3. Press the upper part of the ProClip forward so the thin edge goes into the upper part of the air vent. When the edge on the upper part is positioned by the frame surrounding the air vent: release the pressure so the ProClip flexes back and the adhesive tape attaches to the upper edge of the air vent. Pull out the gap opener.

4. The ProClip is in place.