

Manual, Assembly instruction: Brodit 854861

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the center console and the dashboard.
2. Pull the lower part of the ProClip downward and hook the angled edge over the lower edge of the air vent.
3. Press downward on the lower part of the ProClip so the angled edge hooks into place properly and the adhesive tape attaches.
4. The ProClip is in place. This ProClip can also be placed over the right air vent.