

Manual, Assembly instruction: Brodit 854869

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape covers on the ProClip. Hook the angled top part of the ProClip under the upper edge of the frame surrounding the air vent.
2. Press uppfard/forward on the lower part of the ProClip. Hook the angled lower edge of the ProClip into the gap between the air vent and the surrounding frame.
3. Press firmly so the adhesive tape attaches properly.
4. The ProClip is in place.