

Manual, Assembly instruction: Brodit 854874

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip. This ProClip can be placed anywhere within the width of the air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Hook the angled edge on the lower part of the ProClip into the gap between the control panel and the dashboard.
3. Press the upper part of the ProClip forward so the lower part hooks into the gap properly. Press the angled upper part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.