

Manual, Assembly instruction: Brodit 854875

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame of the center console and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the right part of the ProClip into the gap below the gap opener.

2. Press forward on the ProClip until it stops. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the control panel and the center console. Hook the angled left side of the ProClip into the gap below the gap opener. Remove the gap opener.

4. The ProClip is in place.