

Manual, Assembly instruction: Brodit 854876

Center mount

1.)



2.)



3.)



4.)



Please read all off the instructions and look at the pictures before attaching the ProClip. It is important this ProClip is placed exactly as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Adjust the air vent downward. Peel off the adhesive tape covers on the ProClip.

2. Press the angled upper part of the ProClip into the gap on the upper side of the air vent. Press until you hear/feel it snaps into place.

3. Adjust the air vent upward. Press the lower part of the ProClip upward/forward so the angled edge goes into the gap in the lower part of the air vent.

4. The ProClip is in place.